



## **INSTALLATION METHODS FOR THE LEAF MAN GUTTER GUARD**

### **FLAT ROOF**

**Step 1:** Clean out the gutters & flush the downpipes.

For Kliplok, Trimdek or other profile, screw flat product to lip of gutter and cut &/or fold around rib or formation of roof and screw into place.

### **TILED ROOF**

#### **Preparation:**

- .1. Measure around the perimeter of the roof line for meterage quantities.
- .2. To ascertain the “step” of the step system, measure from the lip of the gutter to front of the tile (normally 70mm to 85mm wide). This stepdown goes under the first row of tiles creating a Z type formation. The higher tip of the Z sits on the lip of the gutter, the lower under the tiles. When ordering the product, quote the measurement for the step.
- .3. Estimate no of screws needed. Allow 3-4 screws per 1.2metre length.

#### **Step 1:**

Clean out the gutters & flush the downpipes.

#### **Step 2:**

Slide tiles back past the fascia board or in the case of eaves gutter, back past the gutter line.

#### **Step 3:**

Place screws into top of the gutter roll at 300-400mm intervals. (4 screws per sheet would suffice).

#### **Step 4:**

Overlap next sheet by 5ml only.

#### **Step 5:**

At corners or gables, the last 3 tiles cannot be lifted without damaging the mortar. Cut off the desired length and create a double step i.e. fold the step that is already there & fold it in half again – creating a double step. Slide this into place. You may then need to do a bit of snip work to finish off.

#### **Step 6:**

For the Valleys: Two pieces of the folded Leaf Man Gutter Guard are required creating a “Top Hat” affect. The lower part of the Z goes under the cut tiles on either side. Start at the gutter & work your way up. Join the two pieces with a screw at the top.

## **CORRUGATED ROOF**

### Preparation

1. Measure around the perimeter of the roof line for meterage quantities. Add 10% for overlap.
2. Measure length of valleys.
3. Estimate no of screws needed. Allow 13-15 screws per 1.2metre length.
4. Estimate amount of silicone. 1 tube for approx 8-10 metres of product.

### **Step 1:**

Clean out the gutters & flush the downpipes. Check that the gutters are in good condition.

### **Step 2:**

Fold scallops down about 5mm between your thumb & forefinger. Lay in place so that scallops fit neatly into roof corrugation.

### **Step 3:**

Secure to the edge of the guttering with screws.

### **Step 4:**

Along the scalloped edge, place screws every 2<sup>nd</sup> corrugation rise. Align with the existing roof screws.

### **Step 5:**

Apply a thin bead of silicone along scalloped edge of The Leaf Man Gutter Guard

### **Corners:**

Run sheet over hip & cut & screw to fit.

**Valleys:** Flat Leaf Man Gutter Guard is used. Product will need to be snipped on both sides to fit into the sides of the corrugation. Screw into corrugated rise where required. Silicone where hand scalloped.

## **OTHER MATERIALS NEEDED FOR DIY INSTALLATION.**

A set of RH or LH tin snips

Cordless Drill

Silicone Gun

Protective Glove

Ladder - any safety approved ladder

